




**BESCO** d.o.o.

**PROIZVODNJA ELEKTRO MATERIALA**

## UVODNICA-KOLČAK



TIP "U"	U 13	U 16	U 20
Za cev	13,5	16	20
Zun. prem.cevi	18	20	20
Luknjač	22	24	24
Standard	DIN	DIN	IEC
Št. oznaka	PP3	PP4	

Uvodnice uporabljamo pri vpenjanju instalacijske cevi v montažno dozo.

Obdrži prožnost pri nizkih temperaturah...


## PERO



TIP "P"	P 13	P 16	P 20	P 25	P 26	P 32
Za uvodnico	U 13	U 16	U 20	U 25	U 26	U 32
Za spojko	S 13	S 16	S 20	S 25	S 26	S 32
Premer	22	24,5	24,5		37	37
Standard	DIN	DIN	IEC	IEC	DIN	IEC
Št. oznaka	PP15	PP16			PP26	


Pero pritrdi cev v uvodnico ali spojko in zagotavlja kvalitetno in hitro instalacijo.

## ČEP

	<b>TIP "C"</b>	<b>C 13</b>	<b>C 16</b>	<b>C 20</b>	<b>C 25</b>	<b>C 26</b>	<b>C 32</b>
	Za uvodnico	U 13	U 16	U 20	U 25	U 26	U 32
	Za cev	13,5	16	20	25	26	32
	Cev notranji premer	14	16	14	18	26	25
	Standard	DIN	DIN	IEC	IEC	DIN	IEC
	Št. oznaka	PC6	PC7		PC10		


Čep zapira uvodnico ali cev in preprečuje vdor betona v cevi.

## SPOJKA

	<b>TIP "S"</b>	<b>S 13</b>	<b>S 15</b>	<b>S 16</b>	<b>S 20</b>	<b>S 25</b>	<b>S26,32</b>
	za cev	13,5	15	16	20	25	26
	Zun.premer cevi	18	15	20	20	25	32
	standard	DIN	IEC	DIN	IEC	IEC	DIN
	st. oznaka	PP7		PP8			PP24


Spojka so namenjene spajanju rebrastih instalacijskih cevi v betonu ali zidu.

## UVODNICA GIS

	<b>TIP "G"</b>	<b>G 11</b>	<b>G 13</b>	<b>G 16</b>	<b>G 21</b>
	Za uvodnico PG	11	13	16	21
	Zun.premer cevi	13-17	17-19	19-21	21-23
	Št. oznaka	GIS 11	GIS 13	GIS 16	GIS 21

Uporabljajo se pri spojih gibkih cevi s PG kovinsko uvodnico.

## KALOTA


	<b>TIP "K"</b>	<b>K 60</b>	<b>K 80</b>
	Tip doze	Do 60	Do 80
	Zunanji premer	60	80

Kalota omogoča enostavno montažo doze na opaž in zagotavlja dobro tesnenje.

<b>DOZA Z NAVOJEM</b>		
	<b>Tip doze</b>	Do 60      Do 80


<b>KLJUKA + POKROV</b>		
	<b>TIP doze</b>	Do 60      Do 80

## SKOZNIK

	<b>TIP "Sk"</b>	<b>Sk 4</b>	<b>Sk 5</b>	<b>Sk 6</b>	<b>Sk 9</b>	<b>Sk 12</b>
	Notranji premer	4 mm	5 mm	6 mm	9 mm	12 mm

Skozniki blažijo robove izvrtin v pločevini. Varujejo žice, ki so speljani skozi pločevino.

## UVODNICA KRD



### TIP "KRD"

Uvodnica je namenena uvajanju kablov večjega premera  
(od 30 mm do 50 mm ) v elektro omare.